

ASUS AI TouchMedia

Quick Start Guide

E4546 / February 2009

Overview

AI TouchMedia

ASUS AI TouchMedia is the complete multimedia center that enhances the enjoyment of your photos, videos, music and movies.

You can combine the arrow keys on your keyboard and the multimedia touch panel to navigate around ASUS AI TouchMedia. It is convenient for you to select and scroll through the following options.

Music

You can listen to music files (in .mp3, .wav and .wma formats) with visualizations and create your favorite playlists (in the .wpl format) in your preferred order.

Photos

You can view your photos (in JPG, PNG and BMP formats) in a slideshow, and modify your photos with AI TouchMedia. Select the **Browse By** button to sort your photos by folder, by date (date taken or last modified) or by rating.

Videos

AI TouchMedia supports videos in MPEG- 1/2, WMV, WMV-HD, DVR-MS and AVI formats. Select the **Browse By** button to sort your videos by folder, by date (date recorded or last modified) or by rating.

Settings


Select **Settings** on the Main Panel to configure the settings for AI TouchMedia.

Movies

You can play DVD, and Blu-ray Disc (on Blu-ray Optical Drive models) with AI TouchMedia.

Using AI Touch Panel



The AI touch panel helps control ASUS AI TouchMedia when listening to music or watching a movie.




1. Activate ASUS AI TouchMedia
2. Return to the Main menu
3. Go to previous level / folder
4. Enter the folder
5. Mute volume
6. Scroll up
7. Scroll down
8. Play / Pause (when playing)
9. Go to previous level / folder; Go to previous song / chapter (when playing)
10. Enter next level / folder; Go to next song / chapter (when playing)
11. Adjust volume
12. Stop playing

Using AI TouchMedia

1. Double-click the **AI TouchMedia** shortcut on the desktop, or tap on the Launch key (🖱️) on the AI Touch Panel to launch AI TouchMedia.




2. Slide your finger up or down on the center of the AI Touch Panel to scroll and select a function from **Music, Photos, Videos, and Movies** or select **Settings** to configure the multimedia settings.




Slide up or down

3. After you select a function, slide your finger rightward to enter the sub-level and start using the provided functions. You can also tap on the ENTER key (🖱️) on the AI Touch Panel to enter the sub-level.




Slide rightward

- Slide your finger leftward or tap on the BACK key (🔄 BACK) on the AI Touch Panel to return to the previous level if you would like to select and use other functions.



Slide leftward

- To adjust volume, slide rightward or leftward on the volume control area on the AI Touch Panel. You can also tap on the volume keys (🔊) and (🔇)) to adjust volume.



Slide or tap to adjust volume

Copyright Information

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Copyright © 2009 ASUSTeK COMPUTER INC. All Rights Reserved.

Limitation of Liability

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

Service and Support

Visit our multi-language web site at <http://support.asus.com>